








CONNECTORS	COMPATIBLE TO THE FOLLOWING:
 LG KG90	LG KG800 Chocolate, LG KG810, LG KG320, KG225, KG320, KG800, KG920, KG90, VX8500, VX8600
 MOTOROLA V3	A780, E1070, E770v, KRZR K1, L2, L6, L7 I-mode, MPx200, PEBL V6, RAZR maxx V6, RAZR V3, RAZR V3i RAZR V3x, RIZR Z3, SLVR L7, U6, V235, V360, V360v, T10 series, T30 series, lfp-700 series, N10, V220, T300, E1000, E390, E398, E610, E615, E680, E1060, E1070, E1120, E375, E680i, E685, E725, E770, E790, E895, V3
 MOTOROLA V8	V8, E8, Q8, Z8, Z6, V9, U9, A1800, W230, V1600, W510
 NOKIA 6101	N70, N71, N72, N73, N80, N80ie, N90, N91, N918GB, N92, N93, E61, E62, 770, 2865i, 3155i, 3250, 5500, 6070, 6080, 6101, 6102, 6102i, 6103, 6111, 6125, 6126, 6131, 6133, 3136, 6151, 6155i, 6165i, 6233, 6265i, 6270, 6280, 7360, 7370
 NOKIA 6300	8600, 6500, 6500C, 6300, E65, E611, 8800A, 5610, 3500C, 7500, 5700
 SAMSUNG D600	159, W109, X609, X619, X699, X809, X859, X869, C208, D108, D410, D418, D428, D488, D508, E338, E608, E618, E638, E808, E810, E818, P518, P738, X108, X430, X458, X458, X468, X608, Z105, C128, B200, D518, E239, F209, F319, M299, M309, M329, M339, M509, M709, S200, T309, W219, W379, X639, X708, X839, X889, X899, X909, X919, X929, X939, X969, i539, C218, C238, D608, D720, D730, D808, D828, E348, E358, E568, E628, E648, E728, E738, E758, E768, E778, E888, E910, P308, P858, X138, X208, X478, X488, X628, X648, X668, X808, Z130, Z300, Z308, Z500, Z510, Z540, Z700, ZX10, i308, i530, i858, B600, D728, F359, W399, X979, i819, D528, D870, E368, E900, P900, X308, X678, X818, Z150, Z350, Z400, Z550, Z560, Z600, Z710, i310, i320, S4300, Z140V, SGH-D520, D800, D820, D830, D840, D900, E250, E390, E500, E570, E780, E870, E900, P300, P310, X820, X830, Z400
 SAMSUNG G600	G600, M300, M510, G808, M618, M608, L288, I550W, W159, P318